

Use USB_driver_3_0_2_Installer.exe to install the USB drivers for Septentrio receiver AsteRx-i D.
The USB drivers are also installed as part of RxTools.