

Command List

The following table lists the set of commands and arguments supported by the receiver. A full description of the commands can be found in the Reference Guide. Note that, depending on the options enabled on your receiver, some commands may not be supported.

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
sam gam	setAGCMode getAGCMode	Band <i>Band</i>	<i>Mode</i>	<i>Gain</i>						
		+ L1 + L2 + L5 + LBand all	auto frozen manual	0 ... <u>35</u> ... 70 dB						
lai	IstAntennalInfo	Antenna								
		Overview Main Aux1 [antenna name]								
sal gal	setAntennaLocation getAntennaLocation	Antenna <i>Antenna</i>	<i>Mode</i>	<i>DeltaX</i>	<i>DeltaY</i>	<i>DeltaZ</i>				
		+ Aux1 + Base all	auto manual	-1000.0000 ... <u>0.0000</u> ... 1000.0000 m	-1000.0000 ... <u>0.0000</u> ... 1000.0000 m	-1000.0000 ... <u>0.0000</u> ... 1000.0000 m				
sao gao	setAntennaOffset getAntennaOffset	Antenna <i>Antenna</i>	<i>DeltaE</i>	<i>DeltaN</i>	<i>DeltaU</i>	<i>Type (20)</i>	<i>SerialNr (20)</i>	<i>SetupID</i>		
		+ Main + Aux1 all	-1000.0000 ... <u>0.0000</u> ... 1000.0000 m	-1000.0000 ... <u>0.0000</u> ... 1000.0000 m	-1000.0000 ... <u>0.0000</u> ... 1000.0000 m	Unknown	Unknown	<u>0</u> ... 255		
sto gto	setAttitudeOffset getAttitudeOffset	<i>Heading</i>	<i>Pitch</i>							
		-360.000 ... <u>0.000</u> ... 360.000 deg	-90.000 ... <u>0.000</u> ... 90.000 deg							
sbbs gbbs	setBBSamplingMode getBBSamplingMode	<i>Mode</i>								
		BeforeIM AfterIM								
sca gca	setChannelAllocation getChannelAllocation	Channel <i>Channel</i>	<i>Satellite</i>	<i>Search</i>	<i>Doppler</i>	<i>Window</i>				
		+ Ch01 ... Ch60 all	auto G01 ... G32 F01 ... F14 E01 ... E36 S120 ... S158 C01 ... C63 J01 ... J07 I01 ... I14	auto manual	-50000 ... <u>0</u> ... 50000 Hz	1 ... 16000 ... 100000 Hz				
scia gcia	setCheckInternetAvailability getCheckInternetAvailability	<i>Mode</i>								
		off on								
scst gcst	setClockSyncThreshold getClockSyncThreshold	<i>Threshold</i>								
		ClockSteering <u>usec500</u> msec1 msec2 msec3 msec4 msec5								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
sc2f gc2f	setCMRv2Formatting getCMRv2Formatting	<i>ReferenceID</i>								
		0 ... 31								
sc2i gc2i	setCMRv2Interval getCMRv2Interval	Message <i>Message</i>	<i>Interval</i>							
		+ CMR0 + CMR1 + CMR2 + CMR3 all	0.1 ... 1.0 ... 600.0 s							
sc2m gc2m	setCMRv2Message2 getCMRv2Message2	<i>ShortID (8)</i>	<i>LongID (50)</i>	<i>COGO (16)</i>						
		<u>Unknown</u>	<u>Unknown</u>	<u>Unknown</u>						
sc2o gc2o	setCMRv2Output getCMRv2Output	Cd <i>Cd</i>	<i>Messages</i>							
		+ COM1 + COM2 + COM3 + COM4 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + NTR4 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none + <u>CMR0</u> + <u>CMR1</u> + <u>CMR2</u> + <u>CMR3</u> all							
sc2u gc2u	setCMRv2Usage getCMRv2Usage	<i>MsgUsage</i>								
		none + <u>CMR0</u> + <u>CMR1</u> + <u>CMR2</u> + <u>CMR3</u> + <u>CMR0p</u> + <u>CMR0w</u> all								
scm gcm	setCN0Mask getCN0Mask	Signal <i>Signal</i>	<i>Mask</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+GPSL1CA +Reserved2 +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALL1BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +QZSL1CA +QZSL2C +QZSL5 +NAVICL5 all	0...10...60 dB-Hz							
help	IstCommandHelp	Action (255)								
		Overview								
scs gcs	setCOMSettings getCOMSettings	Cd Cd	Rate	DataBits	Parity	StopBits	FlowControl			
		+COM1 +COM2 +COM3 +COM4 all	baud1200 baud2400 baud4800 baud9600 baud19200 baud38400 baud57600 baud115200 baud230400 baud460800 baud500000 baud576000 baud921600 baud1000000 baud1152000 baud1500000 baud2000000 baud2500000 baud3000000 baud3500000 baud4000000	bits8	No	bit1	none RTS CTS			
lcf	IstConfigFile	File								
		Current Boot RxDefault User1 User2								
eccf gcfc	exeCopyConfigFile getCopyConfigFile	Source	Target							
		Current Boot User1 User2 RxDefault	Current Boot User1 User2							
scoc gcoc	setCosmosConfig getCosmosConfig	Enable	CustomerID (24)							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>off</u> on								
scda gcda	setCrossDomainWebAccess getCrossDomainWebAccess	<i>Mode</i>								
		<u>off</u> on								
lcu	lstCurrentUser									
sdcm gdcmm	setDaisyChainMode getDaisyChainMode	DC DC	<i>Mode</i>							
		+ DC1 + DC2 all	<u>Raw</u> ASCII							
sdio gdio	setDataInOut getDataInOut	Cd Cd	<i>Input</i>	<i>Output</i>	<i>Show</i>					
		+ DSK1 + COM1 + COM2 + COM3 + COM4 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + NTR4 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none CMD RTCMv2 RTCMv3 CMRv2 DC1 DC2 ASCIIIN SPARTN <u>auto</u>	none + RTCMv2 + RTCMv3 + CMRv2 + <u>SBF</u> + <u>NMEA</u> DC1 + ASCIIIDisplay + DC1 + DC2 + Encapsulate + LBandBeam1 + LBandBeam2 + LBandBeam3 + LBandBeam4	(<u>off</u>) (on) (waiting)					
sdal gdal	setDefaultAccessLevel getDefaultAccessLevel	<i>Web</i>	<i>FileTransfer</i>	<i>Ip</i>	<i>Com</i>	<i>Usb</i>				
		none Viewer <u>User</u>	none <u>Viewer</u> User	none Viewer <u>User</u>	none Viewer <u>User</u>	none Viewer <u>User</u>				
sdca gdca	setDiffCorrMaxAge getDiffCorrMaxAge	<i>DGPSCorr</i>	<i>RTKCorr</i>	<i>PPPCorr</i>	<i>Iono</i>					
		0.0 ... 400.0 ... 3600.0 s	0.0 ... 20.0 ... 3600.0 s	0.0 ... 0.0 s	0.0 ... 600.0 ... 3600.0 s					
sdcu gdcu	setDiffCorrUsage getDiffCorrUsage	<i>Mode</i>	<i>MaxAge</i>	<i>BaseSelection</i>	<i>BaseID</i>	<i>MovingBase</i>				
		<u>LowLatency</u>	0.1 ... 3600.0 s	<u>auto</u> manual	0 ... 4095	<u>off</u> on				
sdfa gdfa	setDiskFullAction getDiskFullAction	Disk Disk	<i>Action</i>							
		+ DSK1 all	DeleteOldest <u>StopLogging</u>							
ldi	lstDiskInfo	Disk	Directory (60)							
		DSK1 all								
sdds gdds	setDynamicDNS getDynamicDNS	<i>Provider</i>	<i>UserName (40)</i>	<i>Password (40)</i>	<i>Hostname (40)</i>	<i>Bind</i>				

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>off</u> dyndns.org no-ip.com				<u>auto</u> Ethernet				
eeem gecm	exeEchoMessage getEchoMessage	Cd	Message (242)	EndOfLine						
		DSK1 COM1 COM2 COM3 COM4 USB1 USB2 IP10 ... IP17 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5 DC1 DC2	A:Unknown	none + CR + LF all						
sem gem	setElevationMask getElevationMask	Engine <i>Engine</i>	Mask							
		+ Tracking + PVT all	-90 ... 0 ... 90 deg							
smth gmth	setENHTransfoHorizontal getENHTransfoHorizontal	TransfoID <i>TransfoID</i>	DeltaE	DeltaN	E0	N0	AlphaEE	AlphaEN	AlphaNE	AlphaNN
		+ lt1 all	-250.0000 ... 0.0000 ... 250.0000 m	-250.0000 ... 0.0000 ... 250.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-1000.0000 ... 0.0000 ... 1000.0000 ppm	-1000.0000 ... 0.0000 ... 1000.0000 ppm	-1000.0000 ... 0.0000 ... 1000.0000 ppm	-1000.0000 ... 0.0000 ... 1000.0000 ppm
smtv gmtv	setENHTransfoVertical getENHTransfoVertical	TransfoID <i>TransfoID</i>	DeltaH	E0	N0	AlphaHE	AlphaHN			
		+ lt1 all	-250.0000 ... 0.0000 ... 250.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-1000.0000 ... 0.0000 ... 1000.0000 ppm	-1000.0000 ... 0.0000 ... 1000.0000 ppm			
seth geth	setEthernetMode getEthernetMode	Enable								
		<u>off</u> <u>on</u>								
sep gep	setEventParameters getEventParameters	Event <i>Event</i>	Polarity	Delay						
		+ EventA + EventB all	Low2High High2Low	-500.000000 ... 0.000000 ... 500.000000 ms						
sfn gfn	setFileNaming getFileNaming	Cd <i>Cd</i>	NamingType	FileName (20)						
		+ DSK1 all	<u>FileName</u> Incremental IGS15M IGS1H IGS6H IGS24H	<u>log</u>						
sfm gfm	setFrontendMode getFrontendMode	Mode								
		<u>Nominal</u> SingleAnt								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
sfpr gfpr	setFTPPushRINEX getFTPPushRINEX	<i>Server (32)</i>	<i>Path (64)</i>	<i>User (12)</i>	<i>Password (24)</i>					
				<u>anonymous</u>						
sfps gfps	setFTPPushSBF getFTPPushSBF	<i>Server (32)</i>	<i>Path (64)</i>	<i>User (12)</i>	<i>Password (24)</i>					
				<u>anonymous</u>						
efpt gfpt	exeFTPPushTest getFTPPushTest	<i>Server (40)</i>	<i>Path (64)</i>	<i>User (20)</i>	<i>Password (40)</i>					
				<u>anonymous</u>						
efup gfup	exeFTPUpgrade getFTPUpgrade	<i>Server (32)</i>	<i>Path (64)</i>	<i>Login (12)</i>	<i>Password (24)</i>					
				<u>anonymous</u>						
sgd ggd	setGeodeticDatum getGeodeticDatum	<i>TargetDatum</i>								
		WGS84 ETRS89 NAD83 NAD83_PA NAD83_MA GDA94 GDA2020 <u>Default</u> User1 User2								
sgu ggu	setGeoidUndulation getGeoidUndulation	<i>Mode</i>	<i>Undulation</i>							
		<u>auto</u> manual	-250.000 ... 0.000 ... 250.000 m							
sfno gfno	setGlobalFileNamingOptions getGlobalFileNamingOptions	<i>BusyTag</i>								
		off <u>on</u>								
sga gga	setGNSSAttitude getGNSSAttitude	<i>Source</i>	<i>MultiAntennaMod</i>							
		none MovingBase <u>MultiAntenna</u>	+ Float + <u>Fixed</u>							
sgpf ggpf	setGPIOFunctionality getGPIOFunctionality	<i>GPPin</i> <i>GPPin</i>	<i>Mode</i>	<i>Input</i>	<i>Output</i>					
		+ GP1 + GP2 all	<u>Output</u>	<u>none</u>	<u>LevelLow</u> LevelHigh					
shm ghm	setHealthMask getHealthMask	<i>Engine</i> <i>Engine</i>	<i>Mask</i>							
		+ Tracking + PVT all	off <u>on</u>							
shs ghs	setHttpsSettings getHttpsSettings	<i>Protocol</i>								
		+ HTTP + HTTPS all								
lif	lstInternalFile	<i>File</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		Permissions Identification Debug Error SisError DiffCorrError SetupError IPParameters RxMessages								
sim gim	setlonosphereModel getlonosphereModel	<i>Model</i>								
		<u>auto</u> off Klobuchar SBAS MultiFreq KlobucharBeiDou								
sipf gipf	setIPFiltering getIPFiltering	<i>Mode</i>	<i>AddrList (200)</i>							
		<u>off</u> on								
sipp gipp	setIPPortSettings getIPPortSettings	<i>Command</i>	<i>FTPControl</i>							
		1 ... 28784 ... 65535	1 ... 21 ... 65535							
sirs girs	setIPReceiveSettings getIPReceiveSettings	<i>Cd</i> <i>Cd</i>	<i>Port</i>	<i>Mode</i>	<i>TCPAddress (40)</i>					
		+ IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	0 ... 65535	TCP2Way UDP	0.0.0.0					
sisss giss	setIPServerSettings getIPServerSettings	<i>Cd</i> <i>Cd</i>	<i>Port</i>	<i>Mode</i>	<i>UDPAddress (200)</i>					
		+ IPS1 + IPS2 + IPS3 + IPS4 + IPS5 all	0 ... 65535	TCP UDP TCP2Way	255.255.255.255					
sips gips	setIPSettings getIPSettings	<i>Mode</i>	<i>IP (16)</i>	<i>Netmask (16)</i>	<i>Gateway (16)</i>	<i>Domain (63)</i>	<i>DNS1 (16)</i>	<i>DNS2 (16)</i>	<i>MTU</i>	
		DHCP Static	0.0.0.0	255.255.255.0	0.0.0.0		0.0.0.0	0.0.0.0	0 ... 1500	
llbb	lslBandBeams									
slbb glbb	setLBandBeams getLBandBeams	<i>Beam</i> <i>Beam</i>	<i>Frequency</i>	<i>Rate</i>	<i>Name (8)</i>	<i>Region (8)</i>	<i>Usage</i>			
		+ User1 + User2 + User3 + User4 all	1525000000 ... 1559000000 Hz	baud600 baud1200 baud2400 baud4800	Unknown	Unknown	Disabled Enabled			
slcs glcs	setLBandCustomServiceID getLBandCustomServiceID	<i>ServiceID (4)</i>	<i>ScramblingVector</i>	<i>NDAUsage</i>						
		0000	0000	off on						
slsm glsm	setLBandSelectMode getLBandSelectMode	<i>Mode</i>	<i>Service</i>	<i>Beam1</i>	<i>Beam2</i>	<i>Beam3</i>	<i>Beam4</i>			

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>auto</u> off manual	Inmarsat <u>Sapcorda</u>	<u>User1</u> User2 User3 User4 Sapcorda 1 Sapcorda 2	User1 <u>User2</u> User3 User4 Sapcorda 1 Sapcorda 2	User1 User2 <u>User3</u> User4	User1 User2 User3 <u>User4</u>			
slm glm	setLEDMode getLEDMode	<u>GPLED</u>								
		<u>DIFFCORLED</u> PVTLED TRACKLED LOGLED								
slco glco	setLocalCoordOperation getLocalCoordOperation	<u>OpName (100)</u>	<u>ENHTransfo</u>							
		<u>NETWORK</u>	<u>none</u> It1							
llc	lstLocalCoordOperations	Operation								
		Overview								
login	LogIn	<u>UserName (16)</u>	<u>Password (32)</u>							
logout	LogOut									
smv gmv	setMagneticVariance getMagneticVariance	<u>Mode</u>	<u>Variation</u>							
		auto manual	-180.0 ... <u>0.0</u> ... 180.0 deg							
emd gmd	exeManageDisk getManageDisk	Disk	Action							
		<u>DSK1</u>	<u>Unmount</u> Mount Format							
smp gmp	setMarkerParameters getMarkerParameters	<u>MarkerName (60)</u>	<u>MarkerNumber (</u>	<u>MarkerType (20)</u>	<u>StationCode (10)</u>	<u>MonumentIdx</u>	<u>ReceiverIdx</u>	<u>CountryCode (3)</u>		
		<u>SEPT</u>	<u>Unknown</u>	<u>Unknown</u>		<u>0 ... 9</u>	<u>0 ... 9</u>			
smrf gmrf	setMeas3MaxRefInterval getMeas3MaxRefInterval	<u>MaxIntrvl</u>								
		OnlyRef msec500 sec1 sec5 sec10 sec30 sec60								
lmd	lstMIBDescription	File (255)								
		Overview SBFTable								
smm gmm	setMultipathMitigation getMultipathMitigation	<u>Code</u>	<u>Carrier</u>							
		off <u>on</u>	off <u>on</u>							
snrc gnrc	setNetworkRTKConfig getNetworkRTKConfig	<u>NetworkType</u>								
		<u>auto</u> VRS								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
enoc gnoc	exeNMEAOnce getNMEAOnce	Cd	Messages							
		DSK1 COM1 COM2 COM3 COM4 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 NTR4 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	+ALM +DTM +GBS +GGA +GLL +GNS +GRS +GSA +GST +GSV +HDT +RMC +ROT +VTG +ZDA +HRP +LLQ +RBP +RBV +RBD +AVR +GGAaux1 +GGK +GFA +GGQ +LLK +GMP +TFM +SNC +THS							
sno gno	setNMEAOutput getNMEAOutput	Stream <i>Stream</i>	Cd	Messages	Interval					
		+ Stream1 ... Stream10 all	none DSK1 COM1 COM2 COM3 COM4 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 NTR4 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	none +ALM +DTM +GBS +GGA +GLL +GNS +GRS +GSA +GST +GSV +HDT +RMC +ROT +VTG +ZDA +HRP +LLQ +RBP +RBV +RBD +AVR +GGAaux1 +GGK +GFA +GGQ +LLK +GMP +TXTbase +TFM +SNC +THS	off OnChange msec10 msec20 msec40 msec50 msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60					
snp gnp	setNMEAPrecision getNMEAPrecision	NrExtraDigits	Compatibility	LocalDatum	MinStdDev					

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		0 ... 2 ... 3	Nominal Mode1 Mode2	off only	0.000 ... 0.001 ... 1.000 m					
snti gnti	setNMEATalkerID getNMEATalkerID	TalkerID								
		auto GP GN								
snv gnv	setNMEAVersion getNMEAVersion	Version								
		v3x v4x								
snf gnf	setNotchFiltering getNotchFiltering	Notch Notch	Mode	CenterFreq	Bandwidth					
		+ Notch1 + Notch2 + Notch3 all	auto off manual	1100.000 ... 1700.000 MHz	30 ... 1600 kHz					
sntp gntp	setNTPServer getNTPServer	Enable								
		off on								
snmp gnmp	setNtripCasterMountPoints getNtripCasterMountPoints	MountPointID MountPointID	Enable	MPName (32)	ExtServer	UserName (20)	Password (40)	ClientAuth		
		+ MP1 + MP2 + MP3 all	off on		No Yes			none basic		
smfp gmfp	setNtripCasterMPFormat getNtripCasterMPFormat	MountPointID MountPointID	Format	ManualFt (30)	FtDetails (100)					
		+ MP1 + MP2 + MP3 all	RTCMv2 RTCMv3 CMR NMEA RAW manual							
snsc gnsc	setNtripCasterSettings getNtripCasterSettings	Mode	Port	Identifier (100)	TlsPort					
		off on	0 ... 2101 ... 65535	default	0 ... 2102 ... 65535					
sncu gncu	setNtripCasterUsers getNtripCasterUsers	UserID UserID	UserName (20)	Password (40)	MountPoints	MaxClients				
		+ User1 + User2 + User3 + User4 + User5 all			none + MP1 + MP2 + MP3 all	1 ... 10				
snts gnst	setNtripSettings getNtripSettings	Cd Cd	Mode	Caster (40)	Port	UserName (20)	Password (40)	MountPoint (32)	Version	SendGGA
		+ NTR1 + NTR2 + NTR3 + NTR4 all	off Server Client Client-Sapcorda		0 ... 2101 ... 65535				v1 v2	auto off sec1 sec5 sec10 sec60
Inst	IstNTRIPSourceTable	Caster (40)	Port							
			0 ... 2101 ... 65535							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
sntt gnnt	setNtripTlsSettings getNtripTlsSettings	Cd <i>Cd</i>	<i>Enable</i>	<i>Fingerprint (96)</i>						
		+ NTR1 + NTR2 + NTR3 + NTR4 all	off on							
soc goc	setObserverComment getObserverComment	<i>Comment (120)</i>								
		<u>Unknown</u>								
sop gop	setObserverParameters getObserverParameters	<i>Observer (20)</i>	<i>Agency (40)</i>							
		<u>Unknown</u>	<u>Unknown</u>							
spe gpe	setPeriodicEcho getPeriodicEcho	Cd <i>Cd</i>	<i>Message (201)</i>	<i>Interval</i>						
		+ COM1 + COM2 + COM3 + COM4 all	<u>A:Unknown</u>	off once msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60						
sp2p gp2p	setPointToPoint getPointToPoint	SessionID <i>SessionID</i>	<i>Mode</i>	<i>Cd</i>	<i>ClientIP (20)</i>	<i>ServerIP (20)</i>	<i>Auth</i>	<i>Password (40)</i>	<i>ConnectTimeout</i>	<i>ActivityTimeout</i>
		+ P2PP1 all	Off Server	COM1 COM2 COM3 COM4	<u>192.168.50.2</u>	<u>192.168.50.1</u>	<u>None</u> PAP CHAP		<u>60 ... 300 s</u>	<u>10 ... 600 ... 32000 s</u>
spfw gpfw	setPortFirewall getPortFirewall	Interface <i>Interface</i>	<i>OpenPorts</i>	<i>PortList (100)</i>						
		+ Ethernet all	none <u>default</u> all PortList							
epwm gpwm	exePowerMode getPowerMode	Mode								
		<u>ScheduledSleep</u> StandBy								
sp2 gps2	setPPS2Parameters getPPS2Parameters	<i>Interval</i>	<i>Polarity</i>	<i>Delay</i>	<i>TimeScale</i>	<i>MaxSyncAge</i>	<i>PulseWidth</i>			

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>off</u> msec10 msec20 msec50 msec100 msec200 msec250 msec500 sec1 sec2 sec5 sec10 sec30 sec60	<u>Low2High</u> High2Low	-1000000.00 ... <u>0.00</u> ... 1000000.00 ns	<u>GPS</u> Galileo BeiDou GLONASS UTC RxClock	0 ... <u>60</u> ... 3600 s	0.001 ... <u>5.000</u> ... 1000.000 ms			
spps gpps	setPPSPParameters getPPSPParameters	<i>Interval</i>	<i>Polarity</i>	<i>Delay</i>	<i>TimeScale</i>	<i>MaxSyncAge</i>	<i>PulseWidth</i>			
		off msec10 msec20 msec50 msec100 msec200 msec250 msec500 <u>sec1</u> sec2 sec5 sec10 sec30 sec60	Low2High High2Low	-1000000.00 ... <u>0.00</u> ... 1000000.00 ns	<u>GPS</u> Galileo BeiDou GLONASS UTC RxClock	0 ... <u>60</u> ... 3600 s	0.001 ... <u>5.000</u> ... 1000.000 ms			
spm gpm	setPVTMode getPVTMode	<i>Mode</i>	<i>RoverMode</i>	<i>RefPos</i>						
		Static <u>Rover</u>	+ StandAlone + SBAS + DGPS + RTKFloat + RTKFixed + RTK all	auto Geodetic1 Geodetic2 Geodetic3 Geodetic4 Geodetic5 Cartesian1 Cartesian2 Cartesian3 Cartesian4 Cartesian5						
srl grl	setRAIMLevels getRAIMLevels	<i>Mode</i>	<i>Pfa</i>	<i>Pmd</i>	<i>Reliability</i>					
		off <u>on</u>	-12 ... <u>4</u> ... -1	-12 ... <u>4</u> ... -1	-12 ... <u>3</u> ... -1					
grc	getReceiverCapabilities									
srd grd	setReceiverDynamics getReceiverDynamics	<i>Level</i>	<i>Motion</i>							
		Max High <u>Moderate</u> Low	Static Quasistatic Pedestrian <u>Automotive</u> RaceCar HeavyMachinery UAV Unlimited							
gri	getReceiverInterface	<i>Item</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ RxName + SNMPLanguage + SNMPVersion all								
lrf	IstRecordedFile	Disk	FileName (60)							
		DSK1								
srom grom	setREFOUTMode getREFOUTMode	Enable								
		off on								
era gra	exeRegisteredApplications getRegisteredApplications	Cd Cd	Application (12)							
		+ COM1 + COM2 + COM3 + COM4 + USB1 + USB2 + IP10 ... IP17 all	Unknown							
erf grf	exeRemoveFile getRemoveFile	Disk	FileName (200)							
		DSK1	none all							
ernf grnf	exeResetNavFilter getResetNavFilter	Level								
		+ PVT + AmbRTK + GNSSAttitude + AmbGNSSAttitud all								
erst grst	exeResetReceiver getResetReceiver	Level	EraseMemory							
		Soft Hard Upgrade	none + Config + PVTData + SatData + HTTPSCertificate all							
srxl grxl	setRINEXLogging getRINEXLogging	Cd Cd	FileDuration	ObsInterval	SignalTypes	ExtraObsTypes	RINEXVersion	MixedNav		

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ <u>DSK1</u> all	<u>none</u> hour1 hour6 hour24 minute15	<u>sec1</u> sec2 sec5 sec10 sec15 sec30 sec60	<u>none</u> + <u>GPSL1CA</u> + <u>GPSL2PY</u> + <u>GPSL2C</u> + <u>GPSL5</u> + <u>GLOL1CA</u> + <u>GLOL2P</u> + <u>GLOL2CA</u> + <u>GLOL3</u> + <u>GALL1BC</u> + <u>GALE5a</u> + <u>GALE5b</u> + <u>GALE5</u> + <u>GEOL1</u> + <u>GEOL5</u> + <u>BDSB1I</u> + <u>BDSB2I</u> + <u>BDSB3I</u> + <u>BDSB1C</u> + <u>BDSB2a</u> + <u>QZSL1CA</u> + <u>QZSL2C</u> + <u>QZSL5</u> + <u>NAVICL5</u> all	<u>none</u> + Dx + Sx + Channel all	v2x v3x	off on		
sr2c gr2c	setRTCMv2Compatibility getRTCMv2Compatibility	<i>PRCType</i>	<i>GLOToD</i>	<i>RTKVersion</i>						
		<u>Standard</u> GroupDelay	<u>Tk</u> Tb	v2.1 <u>v2.2orLater</u>						
sr2f gr2f	setRTCMv2Formatting getRTCMv2Formatting	<i>ReferenceID</i>	<i>GLOToD</i>							
		<u>0 ... 1023</u>	<u>Tk</u> Tb							
sr2i gr2i	setRTCMv2Interval getRTCMv2Interval	Message <i>Message</i>	<i>ZCount</i>							
		+ RTCM1 + RTCM3 + RTCM9 + RTCM16 + RTCM17 + RTCM22 + RTCM23 24 + RTCM31 + RTCM32 all	1 ... 2 ... 1000							
sr2b gr2b	setRTCMv2IntervalObs getRTCMv2IntervalObs	Message <i>Message</i>	<i>Interval</i>							
		+ RTCM18 19 + RTCM20 21 all	1 ... 600 s							
sr2m gr2m	setRTCMv2Message16 getRTCMv2Message16	<i>Message (90)</i>								
		<u>Unknown</u>								
sr2o gr2o	setRTCMv2Output getRTCMv2Output	Cd <i>Cd</i>	Messages							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ COM1 + COM2 + COM3 + COM4 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + NTR4 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none + <u>RTCM1</u> + <u>RTCM3</u> + <u>RTCM9</u> + <u>RTCM16</u> + <u>RTCM18 19</u> + <u>RTCM20 21</u> + <u>RTCM22</u> + <u>RTCM23 24</u> + <u>RTCM31</u> + <u>RTCM32</u> + <u>RTCM17</u> + DGPS + RTK all							
sr2u gr2u	setRTCMv2Usage getRTCMv2Usage	<i>MsgUsage</i>								
		none + <u>RTCM1</u> + <u>RTCM3</u> + <u>RTCM9</u> + <u>RTCM15</u> + <u>RTCM18 19</u> + <u>RTCM20 21</u> + <u>RTCM22</u> + <u>RTCM23 24</u> + <u>RTCM31</u> + <u>RTCM32</u> + <u>RTCM34</u> + <u>RTCM17</u> + <u>RTCM59</u> all								
sr3t gr3t	setRTCMv3CRSTransfo getRTCMv3CRSTransfo	<i>Mode</i>	<i>TargetName (32)</i>							
		auto manual								
sr3d gr3d	setRTCMv3Delay getRTCMv3Delay	<i>Delay</i>								
		0.0 ... 600.0 s								
sr3f gr3f	setRTCMv3Formatting getRTCMv3Formatting	<i>ReferenceID</i>	<i>MSMSignals</i>	<i>GL0L2</i>	<i>RxType (32)</i>					

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		0 ... 4095	+GPSL1CA +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALL1BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +QZSL1CA +QZSL2C +QZSL5 +NAVICL5 all	L2CA L2P	default					
sr3i gr3i	setRTCMv3Interval getRTCMv3Interval	Message Message	Interval							
		+RTCM1001 2 +RTCM1003 4 +RTCM1005 6 +RTCM1007 8 +RTCM1009 10 +RTCM1011 12 +RTCM1013 +RTCM1019 +RTCM1020 +RTCM1029 +RTCM1033 +RTCM1042 +RTCM1044 +RTCM1045 +RTCM1046 +RTCM1230 +MSM1 ... MSM7 all	0.1 ... 1.0 ... 600.0 s							
sr3m gr3m	setRTCMv3Message1029 getRTCMv3Message1029	Message (120)								
		Unknown								
sr3o gr3o	setRTCMv3Output getRTCMv3Output	Cd Cd	Messages							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ COM1 + COM2 + COM3 + COM4 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + NTR4 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none + RTCM1001 + RTCM1002 + RTCM1003 + RTCM1004 + RTCM1005 + RTCM1006 + RTCM1007 ... RTCM1013 + RTCM1019 + RTCM1020 + RTCM1029 + <u>RTCM1033</u> + RTCM1042 + RTCM1044 + RTCM1045 + RTCM1046 + RTCM1071 + RTCM1072 + RTCM1073 + <u>RTCM1074</u> + RTCM1075 + RTCM1076 + RTCM1077 + RTCM1081 + RTCM1082 + RTCM1083 + <u>RTCM1084</u> + RTCM1085 + RTCM1086 + RTCM1087 + RTCM1091 + RTCM1092 + RTCM1093 + <u>RTCM1094</u> + RTCM1095 + RTCM1096 + RTCM1097 + RTCM1101 ... RTCM1107 + RTCM1111 ... RTCM1117 + RTCM1121 + RTCM1122 + RTCM1123 + <u>RTCM1124</u> + RTCM1125 + RTCM1126 + RTCM1127 + RTCM1131 ... RTCM1137 + <u>RTCM1230</u> + MSM1 + MSM2 + MSM3 + MSM4 + MSM5 + MSM6 + MSM7 all							
sr3u gr3u	setRTCMv3Usage getRTCMv3Usage	<i>MsgUsage</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		none + RTCM1001 ... RTCM1013 + RTCM1015 + RTCM1016 + RTCM1017 + RTCM1019 ... RTCM1027 + RTCM1029 + RTCM1033 + RTCM1037 + RTCM1038 + RTCM1039 + RTCM1042 + RTCM1044 + RTCM1045 + RTCM1046 + RTCM1071 ... RTCM1077 + RTCM1081 ... RTCM1087 + RTCM1091 ... RTCM1097 + RTCM1111 ... RTCM1117 + RTCM1121 ... RTCM1127 + RTCM1230 + MSM1 + MSM2 + MSM3 + MSM4 + MSM5 + MSM6 + MSM7 all								
sst	setSatelliteTracking	Satellite								
gst	getSatelliteTracking									
		none + G01 ... G32 + R01 ... R30 + E01 ... E36 + S120 ... S158 + C01 ... C63 + J01 ... J07 + I01 ... I14 + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS + NAVIC all								
ssu	setSatelliteUsage	Satellite								
gsu	getSatelliteUsage									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		none + G01 ... G32 + R01 ... R24 + R25 + R26 + R27 + R28 + R29 + R30 + E01 ... E36 + S120 ... S158 + C01 ... C63 + J01 ... J07 + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS all								
ssbc gsbc	setSBASCorrections getSBASCorrections	<i>Satellite</i>	<i>SISMode</i>	<i>NavMode</i>	<i>DO229Version</i>					
		<u>auto</u> EGNOS WAAS MSAS GAGAN SDCM S120 ... S158	Test <u>Operational</u>	EnRoute PrecApp <u>MixedSystems</u>	<u>auto</u> DO229C					
ssgp gsgp	setSBFGroups getSBFGroups	Group <i>Group</i>	<i>Messages</i>							
		+ Group1 + Group2 + Group3 + Group4 all	none [SBF List] + Measurements + Meas3 + RawNavBits + GPS + GLO + GAL + GEO + BDS + QZS + PVTCart + PVTGeod + PVTExtra + Attitude + Time + Events + DiffCorr + Status + LBand + PostProcess + Rinex + RinexMeas3 + Support							
esoc gsoc	exeSBFOnce getSBFOnce	<i>Cd</i>	<i>Messages</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		DSK1 COM1 COM2 COM3 COM4 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 NTR4 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	[SBF List] + Measurements + Meas3 + GPS + GLO + GAL + GEO + BDS + QZS + PVTCart + PVTGeod + PVTExtra + Attitude + Time + Status + LBand + UserGroups + PostProcess + Rinex + RinexMeas3 + Support							
ss0 gso	setSBFOutput getSBFOutput	Stream <i>Stream</i>	<i>Cd</i>	<i>Messages</i>	<i>Interval</i>					
		+ Stream1 ... Stream10 + Res1 + Res2 + Res3 + Res4 all	<i>none</i> DSK1 COM1 COM2 COM3 COM4 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 NTR4 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	<i>none</i> [SBF List] + Measurements + Meas3 + RawNavBits + GPS + GLO + GAL + GEO + BDS + QZS + PVTCart + PVTGeod + PVTExtra + Attitude + Time + Event + DiffCorr + Status + LBand + UserGroups + PostProcess + Rinex + RinexMeas3 + Support	<i>off</i> OnChange msec10 msec20 msec40 msec50 msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60					
snt gnt	setSignalTracking getSignalTracking	<i>Signal</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+GPSL1CA +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALL1BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +QZSL1CA +QZSL2C +QZSL5 +NAVICL5 +GPS +GLONASS +GALILEO +SBAS +BEIDOU +QZSS +NAVIC all								
snu gnu	setSignalUsage getSignalUsage	<i>PVT</i>	<i>NavData</i>							
		+GPSL1CA +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALL1BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +QZSL1CA +QZSL2C +QZSL5 all	+GPSL1CA +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALL1BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +QZSL1CA +QZSL2C +QZSL5 all							
ssi gsi	setSmoothingInterval getSmoothingInterval	<i>Signal</i> <i>Signal</i>	<i>Interval</i>	<i>Alignment</i>						

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+GPSL1CA +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALL1BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +QZSL1CA +QZSL2C +QZSL5 +NAVICL5 all	0 ... 1000 s	0 ... 1000 s						
sspc gspc	setStaticPosCartesian getStaticPosCartesian	Position <i>Position</i>	<i>X</i>	<i>Y</i>	<i>Z</i>	<i>Datum</i>				
		+Cartesian1 +Cartesian2 +Cartesian3 +Cartesian4 +Cartesian5 all	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	WGS84 ETRS89 NAD83 NAD83_PA NAD83_MA GDA94 GDA2020 User1 User2 Other				
sspg gspg	setStaticPosGeodetic getStaticPosGeodetic	Position <i>Position</i>	<i>Latitude</i>	<i>Longitude</i>	<i>Altitude</i>	<i>Datum</i>				
		+Geodetic1 +Geodetic2 +Geodetic3 +Geodetic4 +Geodetic5 all	-90.0000000000 ... 0.0000000000 ... 90.0000000000 deg	-180.0000000000 ... 0.0000000000 ... 180.0000000000 deg	-1000.0000 ... 0.0000 ... 30000.0000 m	WGS84 ETRS89 NAD83 NAD83_PA NAD83_MA GDA94 GDA2020 User1 User2 Other				
stss gtss	setTimeSyncSource getTimeSyncSource	<i>Source</i>								
		none EventA EventB								
sts gts	setTimingSystem getTimingSystem	<i>System</i>								
		Galileo GPS BeiDou auto								
stlp gtlp	setTrackingLoopParameters getTrackingLoopParameters	Signal <i>Signal</i>	<i>DLLBandwidth</i>	<i>PLLBandwidth</i>	<i>MaxTpDLL</i>	<i>MaxTpPLL</i>	<i>Adaptive</i>			

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+GPSL1CA +Reserved2 +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALL1BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +QZSL1CA +QZSL2C +QZSL5 +NAVICL5 all	0.01 ... 0.25 ... 5.00 Hz	1 ... 15 ... 100 Hz	1 ... 100 ... 500 ms	1 ... 10 ... 200 ms	off on			
stm gtm	setTroposphereModel getTroposphereModel	ZenithModel	MappingModel							
		off Saastamoinen MOPS	Niell MOPS							
stp gtp	setTroposphereParameters getTroposphereParameters	Temperature	Pressure	Humidity						
		-100.0 ... 15.0 ... 100.0 degC	800.00 ... 1013.25 ... 1500.00 hPa	0 ... 50 ... 100 %						
suoc guoc	setUMSDOnConnect getUMSDOnConnect	Mode								
		off on								
suia guia	setUSBInternetAccess getUSBInternetAccess	Enable								
		off on								
sual gual	setUserAccessLevel getUserAccessLevel	UserID UserID	UserName (16)	Password (32)	UserLevel	SSHKey (232)				
		+ User1 ... User8 all			Viewer User					
sud gud	setUserDatum getUserDatum	Datum Datum	Tx	Ty	Tz	Rx	Ry	Rz	D	
		+ User1 + User2 all	-2000000.00 ... 0.00 ... 2000000.00 mm	-2000000.00 ... 0.00 ... 2000000.00 mm	-2000000.00 ... 0.00 ... 2000000.00 mm	-100.0000 ... 0.0000 ... 100.0000 mas	-100.0000 ... 0.0000 ... 100.0000 mas	-100.0000 ... 0.0000 ... 100.0000 mas	-100.00000 ... 0.00000 ... 100.00000 ppb	
sudv gudv	setUserDatumVel getUserDatumVel	Datum Datum	TxVel	TyVel	TzVel	RxVel	RyVel	RzVel	DVel	RefYear
		+ User1 + User2 all	-2000.00 ... 0.00 ... 2000.00 mm/yr	-2000.00 ... 0.00 ... 2000.00 mm/yr	-2000.00 ... 0.00 ... 2000.00 mm/yr	-10.0000 ... 0.0000 ... 10.0000 mas/yr	-10.0000 ... 0.0000 ... 10.0000 mas/yr	-10.0000 ... 0.0000 ... 10.0000 mas/yr	-1.00000 ... 0.00000 ... 1.00000 ppb/yr	1900.00 ... 2000.00 ... 2100.00 yr
sue gue	setUserEllipsoid getUserEllipsoid	Datum Datum	A	Invf						
		+ User1 + User2 all	6300000.000 ... 6378137.000 ... 6400000.000 m	290.000000000 ... 298.25722356 ... 305.000000000						
swui gwui	setWakeUpInterval getWakeUpInterval	WakeUpTime (30)	AwakeDuration	RepetitionPeriod						

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		2000-01-01 00:00:00	0 ... 604800 s	0 ... 604800 s						
swbi gwbi	setWBIMitigation getWBIMitigation	Mode								
		off on								

SBF List

ASCIIn	AttCovEuler	AttEuler
AuxAntPositions	BBSamples	BDSAlm
BDSIon	BDSNav	BDSRaw
BDSRawB1C	BDSRawB2a	BDSUtc
BaseStation	BaseVectorCart	BaseVectorGeod
ChannelStatus	Commands	Comment
CosmosStatus	DOP	DiffCorrIn
DiskStatus	DynDNSStatus	EndOfAtt
EndOfMeas	EndOfPVT	ExtEvent
ExtEventAttEuler	ExtEventBaseVectGeod	ExtEventPVTCartesian
ExtEventPVTGeodetic	GALAlm	GALGstGps
GALIon	GALNav	GALRawFNAV
GALRawINAV	GALSARRLM	GALUtc
GEOAlm	GEOClockEphCovMatrix	GEODegrFactors
GEOFastCorr	GEOFastCorrDegr	GEOIGPMask
GEOIntegrity	GEOIonoDelay	GEOLongTermCorr
GEOMT00	GEONav	GEONetworkTime
GEOPRNMmask	GEORawL1	GEORawL5
GEOServiceLevel	GLOAlm	GLONav
GLORawCA	GLOTime	GPSAlm
GPSIon	GPSNav	GPSRawCA
GPSRawL2C	GPSRawL5	GPSUtc
Group1	Group2	Group3
Group4	IPStatus	InputLink
LBandBeams	LBandTrackerStatus	Meas3CN0HiRes
Meas3Doppler	Meas3MP	Meas3PP
Meas3Ranges	MeasEpoch	MeasExtra
NAVICRaw	NTRIPClientStatus	NTRIPServerStatus
OutputLink	P2PPStatus	PVTCartesian
PVTGeodetic	PVTSupport	PVTSupportA
PosCart	PosCovCartesian	PosCovGeodetic
PosLocal	PosProjected	QZSAlm
QZSNav	QZSRawL1CA	QZSRawL2C
QZSRawL5	QualityInd	RFStatus
RTCMDatum	ReceiverSetup	ReceiverStatus
ReceiverTime	RxMessage	SatVisibility
VelCovCartesian	VelCovGeodetic	xPPSOffset