

# Command List

The following table lists the set of commands and arguments supported by the receiver. A full description of the commands can be found in the Reference Guide. Note that, depending on the options enabled on your receiver, some commands may not be supported.

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
sam gam	setAGCMode getAGCMode	<b>Band</b> Band	Mode	Gain						
		+ L1 + L2 + L5 all	auto frozen manual	0 ... <u>35</u> ... 70 dB						
lai	lstAntennaInfo	<b>Antenna</b>								
		Overview Main Aux1 [antenna name]								
sat gat	setAntennaType getAntennaType	<b>Antenna</b> Antenna	Type (20)							
		+ Main + Aux1 all	Unknown							
sav gav	setAntennaVoltage getAntennaVoltage	Voltage								
		volts3.3 volts5.0								
sto gto	setAttitudeOffset getAttitudeOffset	Heading	Pitch							
		-360.000 ... 0.000 ... 360.000 deg	-90.000 ... 0.000 ... 90.000 deg							
sbbs gbbs	setBBSamplingMode getBBSamplingMode	Mode								
		BeforeIM AfterIM								
sca gca	setChannelAllocation getChannelAllocation	<b>Channel</b> Channel	Satellite	Search	Doppler	Window				
		+ Ch01 ... Ch60 all	auto G01 ... G32 F01 ... F14 E01 ... E36 S120 ... S158 C01 ... C63 J01 ... J07	auto manual	-50000 ... 0 ... 50000 Hz	1 ... 16000 ... 100000 Hz				
scia gcia	setCheckInternetAvailability getCheckInternetAvailability	Mode								
		off on								
scst gcst	setClockSyncThreshold getClockSyncThreshold	Threshold								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		ClockSteering usec500 msec1 msec2 msec3 msec4 msec5								
sc2u gc2u	setCMRv2Usage getCMRv2Usage	MsgUsage								
		none + CMR0 + CMR1 + CMR2 + CMR3 + CMR0p + CMR0w all								
scm gcm	setCN0Mask getCN0Mask	Signal Signal	Mask							
		+ GPSL1CA + Reserved2 + GPSL2C + GPSL5 + GLOL1CA + GLOL2P + GLOL2CA + GALL1BC + GALE5a + GALE5b + GALE5 + GEOL1 + GEOL5 + BDSB1I + BDSB2I + BDSB3I + QZSL1CA + QZSL2C + QZSL5 all	0 ... 10 ... 60 dB-Hz							
help	IstCommandHelp	Action (255)								
		Overview								
scs gcs	setCOMSettings getCOMSettings	Cd Cd	Rate	DataBits	Parity	StopBits	FlowControl			
		+ COM1 + COM2 + COM3 all	baud1200 baud2400 baud4800 baud9600 baud19200 baud38400 baud57600 baud115200 baud230400	bits8	No	bit1	none RTS   CTS			
lcf	IstConfigFile	File								
		Current Boot RxDefault User1 User2								
eccf gccf	exeCopyConfigFile getCopyConfigFile	Source	Target							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>Current</u> Boot User1 User2 RxDefault	<u>Current</u> Boot User1 User2							
scda gcda	<b>setCrossDomainWebAccess</b> <b>getCrossDomainWebAccess</b>	<i>Mode</i>								
		<u>off</u> on								
lcu	<b>IstCurrentUser</b>									
sdcm gdc	<b>setDaisyChainMode</b> <b>getDaisyChainMode</b>	<i>DC</i> <i>DC</i>	<i>Mode</i>							
		+ DC1 + DC2 all	<u>Raw</u> ASCII							
sdio gdio	<b>setDataInOut</b> <b>getDataInOut</b>	<i>Cd</i> <i>Cd</i>	<i>Input</i>	<i>Output</i>	<i>Show</i>					
		+ DSK1 + COM1 + COM2 + COM3 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none CMD RTCMv2 RTCMv3 CMRv2 DC1 DC2 NMEA ASCIIIN <u>auto</u>	none + SBF + NMEA + ASCIIIDisplay + DC1 + DC2 + Encapsulate	( <u>off</u> ) (on) (waiting)					
sdal gdal	<b>setDefaultAccessLevel</b> <b>getDefaultAccessLevel</b>	<i>Web</i>	<i>FileTransfer</i>	<i>Ip</i>	<i>Com</i>	<i>Usb</i>				
		none Viewer User	none <u>Viewer</u> User	none Viewer User	none Viewer User	none Viewer User				
sdca gdca	<b>setDiffCorrMaxAge</b> <b>getDiffCorrMaxAge</b>	<i>DGPS</i> Corr	<i>RTK</i> Corr	<i>PPP</i> Corr	<i>Iono</i>					
		0.0 ...400.0 ...3600.0 s	0.0 ...20.0 ...3600.0 s	0.0 ...0.0 s	0.0 ...600.0 ...3600.0 s					
sdcu gdcu	<b>setDiffCorrUsage</b> <b>getDiffCorrUsage</b>	<i>Mode</i>	<i>MaxAge</i>	<i>BaseSelection</i>	<i>BaseID</i>					
		<u>LowLatency</u>	0.1 ...3600.0 s	<u>auto</u> manual	0 ...4095					
sdfa gdfa	<b>setDiskFullAction</b> <b>getDiskFullAction</b>	<i>Disk</i> <i>Disk</i>	<i>Action</i>							
		+ DSK1 all	DeleteOldest <u>StopLogging</u>							
ldi	<b>IstDiskInfo</b>	<i>Disk</i>	<i>Directory (60)</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		DSK1 all								
sdds gdds	<b>setDynamicDNS</b> <b>getDynamicDNS</b>	<i>Provider</i>	<i>UserName (40)</i>	<i>Password (40)</i>	<i>Hostname (40)</i>	<i>Bind</i>				
		off dyndns.org no-ip.com				auto Ethernet				
eecm gecm	<b>exeEchoMessage</b> <b>getEchoMessage</b>	<i>Cd</i>	<i>Message (242)</i>	<i>EndOfLine</i>						
		DSK1 COM1 COM2 COM3 USB1 USB2 IP10 ... IP17 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5 DC1 DC2	A:Unknown	none + CR + LF all						
sem gem	<b>setElevationMask</b> <b>getElevationMask</b>	<i>Engine</i> <i>Engine</i>	<i>Mask</i>							
		+Tracking + PVT all	-90 ... 0 ... 90 deg							
smth gmth	<b>setENHTransfoHorizontal</b> <b>getENHTransfoHorizontal</b>	<i>TransfoID</i> <i>TransfoID</i>	<i>DeltaE</i>	<i>DeltaN</i>	<i>E0</i>	<i>N0</i>	<i>AlphaEE</i>	<i>AlphaEN</i>	<i>AlphaNE</i>	<i>AlphaNN</i>
		+It1 all	-250.0000 ... 0.0000 ... 250.0000 m	-250.0000 ... 0.0000 ... 250.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-1000.0000 ... 0.0000 ... 1000.0000 ppm	-1000.0000 ... 0.0000 ... 1000.0000 ppm	-1000.0000 ... 0.0000 ... 1000.0000 ppm	-1000.0000 ... 0.0000 ... 1000.0000 ppm
smtv gmtv	<b>setENHTransfoVertical</b> <b>getENHTransfoVertical</b>	<i>TransfoID</i> <i>TransfoID</i>	<i>DeltaH</i>	<i>E0</i>	<i>N0</i>	<i>AlphaHE</i>	<i>AlphaHN</i>			
		+It1 all	-250.0000 ... 0.0000 ... 250.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-1000.0000 ... 0.0000 ... 1000.0000 ppm	-1000.0000 ... 0.0000 ... 1000.0000 ppm			
seth geth	<b>setEthernetMode</b> <b>getEthernetMode</b>	<i>Enable</i>								
		off on								
sep gep	<b>setEventParameters</b> <b>getEventParameters</b>	<i>Event</i> <i>Event</i>	<i>Polarity</i>							
		+ EventA + EventB all	Low2High High2Low							
sfn gfn	<b>setFileNaming</b> <b>getFileNaming</b>	<i>Cd</i> <i>Cd</i>	<i>NamingType</i>	<i>FileName (20)</i>						

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ DSK1 all	<u>FileName</u> Incremental IGS15M IGS1H IGS6H IGS24H	<u>log</u>						
sfm gfm	<b>setFrontendMode</b> <b>getFrontendMode</b>	<i>Mode</i>								
		<u>Nominal</u> SingleAnt								
efup gfup	<b>exeFTPUpgrade</b> <b>getFTPUpgrade</b>	<b>Server (32)</b>	<b>Path (64)</b>	<b>Login (12)</b>	<b>Password (24)</b>					
				<u>anonymous</u>						
lopk	<b>IstGalOSNMAPublicKeys</b>									
sopk gopk	<b>setGalOSNMAPublicKeys</b> <b>getGalOSNMAPublicKeys</b>	<b>ID</b> <i>ID</i>	<b>Key (233)</b>							
		+ Key0 ... Key15 all								
sou gou	<b>setGalOSNMAUsage</b> <b>getGalOSNMAUsage</b>	<i>Mode</i>	<i>MTRoot (65)</i>							
		<u>off</u> loose strict								
sgd ggd	<b>setGeodeticDatum</b> <b>getGeodeticDatum</b>	<i>TargetDatum</i>								
		WGS84 ETRS89 NAD83 NAD83_PA NAD83_MA GDA94 GDA2020 <u>Default</u> User1 User2								
sgu ggg	<b>setGeoidUndulation</b> <b>getGeoidUndulation</b>	<i>Mode</i>	<i>Undulation</i>							
		<u>auto</u> manual	-250.000 ... 0.000 ... 250.000 m							
sfno gfno	<b>setGlobalFileNamingOptions</b> <b>getGlobalFileNamingOptions</b>	<i>BusyTag</i>								
		<u>off</u> <u>on</u>								
sga gga	<b>setGNSSAttitude</b> <b>getGNSSAttitude</b>	<i>Source</i>								
		none <u>MultiAntenna</u>								
sgpf ggpf	<b>setGPIOFunctionality</b> <b>getGPIOFunctionality</b>	<b>GPPin</b> <i>GPPin</i>	<i>Mode</i>	<i>Input</i>	<i>Output</i>					
		+ GP1 + GP2 all	<u>Output</u>	<u>none</u>	<u>LevelLow</u> LevelHigh					
shm ghm	<b>setHealthMask</b> <b>getHealthMask</b>	<b>Engine</b> <i>Engine</i>	<i>Mask</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+Tracking +PVT all	off <u>on</u>							
shs ghs	setHttpsSettings getHttpsSettings	Protocol								
		+HTTP +HTTPS all								
sio gio	setIMUOrientation getIMUOrientation	OrientationMode	ThetaX	ThetaY	ThetaZ					
		SensorDefault manual	-180.000 ...0.000 ...180.000 deg	-90.000 ...0.000 ...90.000 deg	-180.000 ...0.000 ...180.000 deg					
sial gial	setINSantLeverArm getINSantLeverArm	X	Y	Z						
		-100.000 ...0.000 ...100.000 m	-100.000 ...0.000 ...100.000 m	-100.000 ...0.000 ...100.000 m						
siih giih	setINSInitialHeading getINSInitialHeading	Mode								
		auto stored								
sinc ginc	setINSNavConfig getINSNavConfig	Mode	OutputType	OutputLocation						
		off <u>on</u>	none + PosStdDev + Att + AttStdDev + Vel + VelStdDev all	MainAnt POI1						
sipl gipl	setINSPOILeverArm getINSPOILeverArm	POI POI	X	Y	Z					
		+POI1 all	-100.000 ...0.000 ...100.000 m	-100.000 ...0.000 ...100.000 m	-100.000 ...0.000 ...100.000 m					
sism gism	setINSStdDevMask getINSStdDevMask	AttStdDev	PosStdDev							
		0.000 ...2.000 ...5.000 deg	0.000 ...100.000 m							
sivl givl	setINSVelSensorLeverArm getINSVelSensorLeverArm	SensorId SensorId	X	Y	Z					
		+VSM1 all	-100.000 ...0.000 ...100.000 m	-100.000 ...0.000 ...100.000 m	-100.000 ...0.000 ...100.000 m					
lif	lstInternalFile	File								
		Permissions Identification Debug Error SisError DiffCorrError ExtSensorError SetupError IPPParameters RxMessages								
sim gim	setlonosphereModel getlonosphereModel	Model								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>auto</u> <u>off</u> Klobuchar SBAS MultiFreq KlobucharBeiDou								
sipf gipf	<b>setIPFiltering</b> <b>getIPFiltering</b>	<i>Mode</i>	<i>AddrList (200)</i>							
		<u>off</u> <u>on</u>								
sipk gipk	<b>setIPKeepAlive</b> <b>getIPKeepAlive</b>	<i>Enable</i>	<i>IdleTime</i>	<i>Interval</i>	<i>MaxCount</i>					
		<u>off</u> <u>on</u>	<u>15 ... 18000 s</u>	<u>1 ... 3600 s</u>	<u>1 ... 15 ... 3600</u>					
sipp gipp	<b>setIPPortSettings</b> <b>getIPPortSettings</b>	<i>Command</i>	<i>FTPControl</i>							
		<u>1 ... 28784</u> <u>... 65535</u>	<u>1 ... 21</u> <u>... 65535</u>							
sirs girs	<b>setIPReceiveSettings</b> <b>getIPReceiveSettings</b>	<b><i>Cd</i></b> <i>Cd</i>	<i>Port</i>	<i>Mode</i>	<i>TCPAddress (40)</i>					
		+ IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	<u>0 ... 65535</u>	<u>TCP2Way</u> UDP	<u>0.0.0.0</u>					
sisss giss	<b>setIPServerSettings</b> <b>getIPServerSettings</b>	<b><i>Cd</i></b> <i>Cd</i>	<i>Port</i>	<i>Mode</i>	<i>UDPAddress (200)</i>					
		+ IPS1 + IPS2 + IPS3 + IPS4 + IPS5 all	<u>0 ... 65535</u>	<u>TCP</u> UDP TCP2Way	<u>255.255.255.255</u>					
sips gips	<b>setIPSettings</b> <b>getIPSettings</b>	<i>Mode</i>	<i>IP (16)</i>	<i>Netmask (16)</i>	<i>Gateway (16)</i>	<i>Domain (63)</i>	<i>DNS1 (16)</i>	<i>DNS2 (16)</i>	<i>MTU</i>	
		DHCP Static	<u>0.0.0.0</u>	<u>255.255.255.0</u>	<u>0.0.0.0</u>		<u>0.0.0.0</u>	<u>0.0.0.0</u>	<u>0 ... 1500</u>	
slco glco	<b>setLocalCoordOperation</b> <b>getLocalCoordOperation</b>	<i>OpName (100)</i>	<i>ENHTransfo</i>							
		NETWORK	<u>none</u> lt1							
llc	<b>IstLocalCoordOperations</b>	<b><i>Operation</i></b>								
		Overview								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
login	<b>LogIn</b>	<i>UserName (16)</i>	<i>Password (32)</i>							
logout	<b>LogOut</b>									
smv gmrv	<b>setMagneticVariance</b> <b>getMagneticVariance</b>	<i>Mode</i>	<i>Variation</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		auto manual	-180.0 ... 0.0 ... 180.0 deg							
emd gmd	exeManageDisk getManageDisk	<b>Disk</b>	<b>Action</b>							
		DSK1	Unmount Mount Format							
smp gmp	setMarkerParameters getMarkerParameters	MarkerName (60)	MarkerNumber (	MarkerType (20)						
		SEPT	Unknown	Unknown						
smrf gmrf	setMeas3MaxRefInterval getMeas3MaxRefInterval	MaxIntrvl								
		OnlyRef msec500 sec1 sec5 sec10 sec30 sec60								
lmd	lstMIBDescription	<b>File (255)</b>								
		Overview SBFTable								
smm gmm	setMultipathMitigation getMultipathMitigation	Code	Carrier							
		off on	off on							
snrc gnrc	setNetworkRTKConfig getNetworkRTKConfig	NetworkType								
		auto VRS								
enoc gnoc	exeNMEAOnce getNMEAOnce	<b>Cd</b>	<b>Messages</b>							
		DSK1 COM1 COM2 COM3 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	+ GGA + GLL + <u>GNS</u> + GST + HDT + RMC + VTG + ZDA + HRP + THS + PASHR							
sno gno	setNMEAOutput getNMEAOutput	<b>Stream</b> Stream	Cd	Messages	Interval					



Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ Stream1 Stream10 all	... <u>none</u> DSK1 COM1 COM2 COM3 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	<u>none</u> + GGA + GLL + GNS + GST + HDT + RMC + VTG + ZDA + HRP + THS + PASHR	<u>off</u> OnChange msec5 msec10 msec20 msec40 msec50 msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60					
snp gnp	<b>setNMEAPrecision</b> <b>getNMEAPrecision</b>	<i>NrExtraDigits</i>	<i>Compatibility</i>	<i>LocalDatum</i>	<i>MinStdDev</i>					
		0 ... 2 ... 3	<u>Nominal</u> Mode1 Mode2 Mode3	<u>off</u> only	0.000 ... 0.001 ... 1.000 m					
snti gnti	<b>setNMEATalkerID</b> <b>getNMEATalkerID</b>	<i>TalkerID</i>								
		<u>auto</u> GP								
snv gnv	<b>setNMEAVersion</b> <b>getNMEAVersion</b>	<i>Version</i>								
		<u>v3x</u> v4x								
snf gnf	<b>setNotchFiltering</b> <b>getNotchFiltering</b>	<b>Notch</b> <i>Notch</i>	<i>Mode</i>	<i>CenterFreq</i>	<i>Bandwidth</i>					
		+ Notch1 + Notch2 + Notch3 all	<u>auto</u> off manual	<u>1100.000</u> ... 1700.000 MHz	<u>30</u> ... 1600 kHz					
snc gnc	<b>setNtpClient</b> <b>getNtpClient</b>	<i>Mode</i>	<i>Server (40)</i>							
		on <u>off</u>	<u>default</u>							
sntp gntp	<b>setNTPServer</b> <b>getNTPServer</b>	<i>Enable</i>								
		<u>off</u> on								
snts gnTs	<b>setNtripSettings</b> <b>getNtripSettings</b>	<b>Cd</b> <i>Cd</i>	<i>Mode</i>	<i>Caster (40)</i>	<i>Port</i>	<i>UserName (20)</i>	<i>Password (40)</i>	<i>MountPoint (32)</i>	<i>Version</i>	<i>SendGGA</i>
		+ NTR1 + NTR2 + NTR3 all	<u>off</u> Client		<u>0</u> ... <u>2101</u> ... 65535				v1 <u>v2</u>	<u>auto</u> off sec1 sec5 sec10 sec60
Inst	<b>IstNTRIPSourceTable</b>	<b>Caster (40)</b>	<i>Port</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
			0 ... 2101 ... 65535							
sntt gntt	setNtripTlsSettings getNtripTlsSettings	Cd Cd	Enable	Fingerprint (96)						
		+ NTR1 + NTR2 + NTR3 all	off on							
soc goc	setObserverComment getObserverComment	Comment (120)								
		Unknown								
sop gop	setObserverParameters getObserverParameters	Observer (20)	Agency (40)							
		Unknown	Unknown							
spe gpe	setPeriodicEcho getPeriodicEcho	Cd Cd	Message (201)	Interval						
		+ COM1 + COM2 + COM3 all	A:Unknown	off once msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60						
spfw gpfw	setPortFirewall getPortFirewall	Interface Interface	OpenPorts	PortList (100)						
		+ Ethernet all	none default all PortList							
epwm gpwm	exePowerMode getPowerMode	Mode								
		ScheduledSleep StandBy								
spps gpsps	setPPSPParameters getPPSPParameters	Interval	Polarity	Delay	TimeScale	MaxSyncAge	PulseWidth			
		off msec10 msec20 msec50 msec100 msec200 msec250 msec500 sec1 sec2 sec4 sec5 sec10 sec30 sec60	Low2High High2Low	-1000000.00 ... 0.00 ... 1000000.00 ns	GPS Galileo BeiDou GLONASS UTC RxClock	0 ... 3600 s	0.001 ... 5.000 ... 1000.000 ms			
spm gpm	setPVTMode getPVTMode	Mode	RoverMode							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>Rover</u>	+ <u>StandAlone</u> + <u>SBAS</u> + <u>DGPS</u> + <u>RTKFloat</u> + <u>RTKFixed</u> + <u>RTK</u> all							
srl grl	<b>setRAIMLevels</b> <b>getRAIMLevels</b>	<i>Mode</i>	<i>Pfa</i>	<i>Pmd</i>	<i>Reliability</i>					
		off on	-12 ... <u>4</u> ... -1	-12 ... <u>4</u> ... -1	-12 ... <u>3</u> ... -1					
grc	<b>getReceiverCapabilities</b>									
srd grd	<b>setReceiverDynamics</b> <b>getReceiverDynamics</b>	<i>Level</i>	<i>Motion</i>							
		Max High <u>Moderate</u> Low	<u>Automotive</u> UAV							
gri	<b>getReceiverInterface</b>	<i>Item</i>								
		+ RxName + SNMPLanguage + SNMPVersion all								
lrf	<b>lstRecordedFile</b>	<i>Disk</i>	<i>FileName (60)</i>							
		DSK1								
era gra	<b>exeRegisteredApplications</b> <b>getRegisteredApplications</b>	<i>Cd</i> <i>Cd</i>	<i>Application (12)</i>							
		+ COM1 + COM2 + COM3 + USB1 + USB2 + IP10 ... IP17 all	<u>Unknown</u>							
erf grf	<b>exeRemoveFile</b> <b>getRemoveFile</b>	<i>Disk</i>	<i>FileName (200)</i>							
		DSK1	<u>none</u> all							
ernf grnf	<b>exeResetNavFilter</b> <b>getResetNavFilter</b>	<i>Level</i>								
		+ <u>PVT</u> + <u>AmbRTK</u> + <u>ExtSensorInt</u> + <u>GNSSAttitude</u> + <u>AmbGNSSAttitud</u> all								
erst grst	<b>exeResetReceiver</b> <b>getResetReceiver</b>	<i>Level</i>	<i>EraseMemory</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		Soft Hard Upgrade	<u>none</u> + Config + PVTData + SatData + IMUData + HTTPSCertificate + SISAuthData all							
sr2c gr2c	<b>setRTCMv2Compatibility</b> <b>getRTCMv2Compatibility</b>	<i>PRCType</i>	<i>GLOToD</i>	<i>RTKVersion</i>						
		<u>Standard</u> GroupDelay	<u>Tk</u> <u>Tb</u>	v2.1 <u>v2.2orLater</u>						
sr2u gr2u	<b>setRTCMv2Usage</b> <b>getRTCMv2Usage</b>	<i>MsgUsage</i>								
		none + RTCM1 + <u>RTCM3</u> + RTCM9 + RTCM15 + <u>RTCM18 19</u> + <u>RTCM20 21</u> + RTCM22 + <u>RTCM23 24</u> + <u>RTCM31</u> + <u>RTCM32</u> + RTCM34 + <u>RTCM17</u> + <u>RTCM59</u> all								
sr3t gr3t	<b>setRTCMv3CRSTransfo</b> <b>getRTCMv3CRSTransfo</b>	<i>Mode</i>	<i>TargetName (32)</i>							
		auto manual								
sr3u gr3u	<b>setRTCMv3Usage</b> <b>getRTCMv3Usage</b>	<i>MsgUsage</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		none + RTCM1001 ... <u>RTCM1013</u> + RTCM1015 + RTCM1016 + RTCM1017 + RTCM1019 ... <u>RTCM1027</u> + RTCM1029 + RTCM1033 + RTCM1037 + RTCM1038 + RTCM1039 + RTCM1042 + RTCM1044 + RTCM1045 + RTCM1046 + RTCM1071 ... <u>RTCM1077</u> + RTCM1081 ... <u>RTCM1087</u> + RTCM1091 ... <u>RTCM1097</u> + RTCM1111 ... <u>RTCM1117</u> + RTCM1121 ... <u>RTCM1127</u> + RTCM1230 + MSM1 + MSM2 + MSM3 + MSM4 + MSM5 + MSM6 + MSM7 all								
sst	<b>setSatelliteTracking</b>	<i>Satellite</i>								
gst	<b>getSatelliteTracking</b>									
		none + G01 ... <u>G32</u> + R01 ... <u>R30</u> + E01 ... <u>E36</u> + S120 ... <u>S158</u> + C01 ... <u>C63</u> + J01 ... <u>J07</u> + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS all								
ssu	<b>setSatelliteUsage</b>	<i>Satellite</i>								
gsu	<b>getSatelliteUsage</b>									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		none + G01 ... G32 + R01 ... R24 + R25 + R26 + R27 + R28 + R29 + R30 + E01 ... E36 + S120 ... S158 + C01 ... C63 + J01 ... J07 + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS all								
ssbc gsbc	<b>setSBASCORRECTIONS</b> <b>getSBASCORRECTIONS</b>	<i>Satellite</i>	<i>SISMode</i>	<i>NavMode</i>	<i>DO229Version</i>					
		auto EGNOS WAAS MSAS GAGAN SDCM S120 ... S158	Test <u>Operational</u>	<u>MixedSystems</u>	auto DO229C					
ssgp gsgp	<b>setSBFGROUPS</b> <b>getSBFGROUPS</b>	<i>Group</i> <i>Group</i>	<i>Messages</i>							
		+ Group1 + Group2 + Group3 + Group4 all	none [SBF List] + Measurements + Meas3 + RawNavBits + GPS + GLO + GAL + GEO + BDS + QZS + PVTCart + PVTGeod + PVTExtra + Attitude + Time + Events + DiffCorr + ExtSensors + Status + PostProcess + Rinex + RinexMeas3 + Support + INSCalibration							
esoc gsoc	<b>exeSBFOnce</b> <b>getSBFOnce</b>	<i>Cd</i>	<i>Messages</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		DSK1 COM1 COM2 COM3 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	[SBF List] + Measurements + Meas3 + GPS + GLO + GAL + GEO + BDS + QZS + PVTCart + PVTGeod + PVTEExtra + Attitude + Time + ExtSensors + Status + UserGroups + PostProcess + Rinex + RinexMeas3 + Support							
sso	setSBFOutput	<b>Stream</b>	<b>Cd</b>	<b>Messages</b>	<b>Interval</b>					
gso	getSBFOutput	<b>Stream</b>								
		+ Stream1 ... Stream10 + Res1 + Res2 + Res3 + Res4 all	none DSK1 COM1 COM2 COM3 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	none [SBF List] + Measurements + Meas3 + RawNavBits + GPS + GLO + GAL + GEO + BDS + QZS + PVTCart + PVTGeod + PVTEExtra + Attitude + Time + Event + DiffCorr + ExtSensors + Status + UserGroups + PostProcess + Rinex + RinexMeas3 + Support + INSCalibration	off OnChange msec5 msec10 msec20 msec40 msec50 msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60					
snt	setSignalTracking	<b>Signal</b>								
gnt	getSignalTracking									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<a href="#">+GPSL1CA</a> <a href="#">+GPSL2PY</a> <a href="#">+GPSL2C</a> <a href="#">+GPSL5</a> <a href="#">+GLOL1CA</a> <a href="#">+GLOL2P</a> <a href="#">+GLOL2CA</a> <a href="#">+GALL1BC</a> <a href="#">+GALE5a</a> <a href="#">+GALE5b</a> <a href="#">+GALE5</a> <a href="#">+GEOL1</a> <a href="#">+GEOL5</a> <a href="#">+BDSB1I</a> <a href="#">+BDSB2I</a> <a href="#">+BDSB3I</a> <a href="#">+QZSL1CA</a> <a href="#">+QZSL2C</a> <a href="#">+QZSL5</a> <a href="#">+GPS</a> <a href="#">+GLONASS</a> <a href="#">+GALILEO</a> <a href="#">+SBAS</a> <a href="#">+BEIDOU</a> <a href="#">+QZSS</a> <a href="#">all</a>								
snu	<b>setSignalUsage</b>	<i>PVT</i>	<i>NavData</i>							
gnu	<b>getSignalUsage</b>									
		<a href="#">+GPSL1CA</a> <a href="#">+GPSL2PY</a> <a href="#">+GPSL2C</a> <a href="#">+GPSL5</a> <a href="#">+GLOL1CA</a> <a href="#">+GLOL2P</a> <a href="#">+GLOL2CA</a> <a href="#">+GALL1BC</a> <a href="#">+GALE5a</a> <a href="#">+GALE5b</a> <a href="#">+GALE5</a> <a href="#">+GEOL1</a> <a href="#">+GEOL5</a> <a href="#">+BDSB1I</a> <a href="#">+BDSB2I</a> <a href="#">+BDSB3I</a> <a href="#">+QZSL1CA</a> <a href="#">+QZSL2C</a> <a href="#">+QZSL5</a> <a href="#">all</a>	<a href="#">+GPSL1CA</a> <a href="#">+GPSL2PY</a> <a href="#">+GPSL2C</a> <a href="#">+GPSL5</a> <a href="#">+GLOL1CA</a> <a href="#">+GLOL2P</a> <a href="#">+GLOL2CA</a> <a href="#">+GALL1BC</a> <a href="#">+GALE5a</a> <a href="#">+GALE5b</a> <a href="#">+GALE5</a> <a href="#">+GEOL1</a> <a href="#">+GEOL5</a> <a href="#">+BDSB1I</a> <a href="#">+BDSB2I</a> <a href="#">+BDSB3I</a> <a href="#">+QZSL1CA</a> <a href="#">+QZSL2C</a> <a href="#">+QZSL5</a> <a href="#">all</a>							
ssi	<b>setSmoothingInterval</b>	<i>Signal</i>	<i>Interval</i>	<i>Alignment</i>						
gsi	<b>getSmoothingInterval</b>	<i>Signal</i>								



Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+GPSL1CA +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GALL1BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +QZSL1CA +QZSL2C +QZSL5 all	0 ... 1000 s	0 ... 1000 s						
sis gts	setTimingSystem getTimingSystem	System								
		Galileo GPS BeiDou auto								
stm gtm	setTroposphereModel getTroposphereModel	ZenithModel	MappingModel							
		off Saastamoinen MOPS	Niell MOPS							
stp gtp	setTroposphereParameters getTroposphereParameters	Temperature	Pressure	Humidity						
		-100.0 ... 15.0 ... 100.0 degC	800.00 ... 1013.25 ... 1500.00 hPa	0 ... 50 ... 100 %						
suoc guoc	setUMSDOnConnect getUMSDOnConnect	Mode								
		off on								
suia guia	setUSBInternetAccess getUSBInternetAccess	Enable								
		off on								
sual gual	setUserAccessLevel getUserAccessLevel	UserID UserID	UserName (16)	Password (32)	UserLevel	SSHKey (232)				
		+ User1 ... User8 all			Viewer User					
sud gud	setUserDatum getUserDatum	Datum Datum	Tx	Ty	Tz	Rx	Ry	Rz	D	
		+ User1 + User2 all	-2000000.00 ... 0.00 ... 2000000.00 mm	-2000000.00 ... 0.00 ... 2000000.00 mm	-2000000.00 ... 0.00 ... 2000000.00 mm	-100.0000 ... 0.0000 ... 100.0000 mas	-100.0000 ... 0.0000 ... 100.0000 mas	-100.0000 ... 0.0000 ... 100.0000 mas	-100.00000 ... 0.00000 ... 100.00000 ppb	
sudv gudv	setUserDatumVel getUserDatumVel	Datum Datum	TxVel	TyVel	TzVel	RxVel	RyVel	RzVel	DVel	RefYear
		+ User1 + User2 all	-2000.00 ... 0.00 ... 2000.00 mm/yr	-2000.00 ... 0.00 ... 2000.00 mm/yr	-2000.00 ... 0.00 ... 2000.00 mm/yr	-10.0000 ... 0.0000 ... 10.0000 mas/yr	-10.0000 ... 0.0000 ... 10.0000 mas/yr	-10.0000 ... 0.0000 ... 10.0000 mas/yr	-1.00000 ... 0.00000 ... 1.00000 ppb/yr	1900.00 ... 2000.00 ... 2100.00 yr
sue gue	setUserEllipsoid getUserEllipsoid	Datum Datum	A	Invf						

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ User1 + User2 all	6300000.000 ...6378137.000 ...6400000.000 m	290.000000000 ...298.25722356 ...305.00000000						
swui gwui	<b>setWakeUpInterval</b> <b>getWakeUpInterval</b>	<i>WakeUpTime (30</i>	<i>AwakeDuration</i>	<i>RepetitionPeriod</i>						
		2000-01-01 00:00:00	0 ...604800 s	0 ...604800 s						
swbi gwbi	<b>setWBIMitigation</b> <b>getWBIMitigation</b>	<i>Mode</i>								
		off on								

# SBF List

ASCIIn	AttCovEuler	AttEuler
AuxAntPositions	BBSamples	BDSAlm
BDSIon	BDSNav	BDSRaw
BDSUtc	BaseStation	BaseVectorCart
BaseVectorGeod	ChannelStatus	Commands
Comment	DOP	DiffCorrIn
DiskStatus	DynDNSStatus	EndOfAtt
EndOfMeas	EndOfPVT	ExtEvent
ExtEventINSNavCart	ExtEventINSNavGeod	ExtSensorInfo
ExtSensorMeas	ExtSensorStatus	GALAlm
GALAuthStatus	GALGstGps	GALLon
GALNav	GALRawFNAV	GALRawINAV
GALSARRLM	GALUtc	GEOAlm
GEOClockEphCovMatrix	GEODegrFactors	GEOFastCorr
GEOFastCorrDegr	GEOIGPMask	GEOIntegrity
GEOlonDelay	GEOLongTermCorr	GEOMT00
GEONav	GEONetworkTime	GEOPRNMMask
GEORawL1	GEORawL5	GEOServiceLevel
GLOAlm	GLONav	GLORawCA
GLOTime	GPSAlm	GPSIon
GPSNav	GPSRawCA	GPSRawL2C
GPSRawL5	GPSUtc	Group1
Group2	Group3	Group4
IMURawSamples	IMUSetup	INSNavCart
INSNavGeod	INSSupport	IPStatus
InputLink	Meas3CN0HiRes	Meas3Doppler
Meas3MP	Meas3PP	Meas3Ranges
MeasEpoch	MeasExtra	NTRIPClientStatus
OutputLink	PVTCartesian	PVTGeodetic
PVTSupport	PVTSupportA	PosCart
PosCovCartesian	PosCovGeodetic	PosLocal
PosProjected	PowerStatus	QZSAlm
QZSNav	QZSRawL1CA	QZSRawL2C
QZSRawL5	QualityInd	RFStatus
RTCMDatum	ReceiverSetup	ReceiverStatus
ReceiverTime	RxMessage	SatVisibility
VelCovCartesian	VelCovGeodetic	VelSensorSetup
xPPSOffset		